


# CP 102

S-DIAS CPU Module

## INSTRUCTION MANUAL

|                   |              |
|-------------------|--------------|
| Article number:   | 20-004-102-E |
| Date of creation: | 06.11.2014   |
| Version date:     | 22.07.2026   |



**Publisher:**

SIGMATEK GmbH & Co KG  
A-5112 Lamprechtshausen  
Tel.: +43/6274/4321  
Fax: +43/6274/4321-18

Email: [office@sigmatek.at](mailto:office@sigmatek.at)  
[www.sigmathek-automation.com](http://www.sigmathek-automation.com)

All rights reserved. No part of this work may be reproduced, edited using an electronic system, duplicated or distributed in any form (print, photocopy, microfilm or in any other process) without express permission.

We reserve the right to make changes in the content without notice. SIGMATEK GmbH & Co KG is not responsible for technical or printing errors in this handbook and assumes no responsibility for damages that occur through its use.

**S-DIAS CPU Module****CP 102****1 Ethernet****1 USB-OTG****1 CAN**

The S-DIAS CPU Module CP 102 is a high-performance processor unit for the S-DIAS I/O modules. With Ethernet, CAN bus and USB OTG (Host and Device) interfaces, the module can be used for various applications. A zero-voltage protected RAM area is available, which is implemented by copying a data block from the DDR RAM to the NAND Flash.

The voltage supply is already available in the module. The number of modules that can be supplied depends on the total current consumption. The CP 102 can supply a maximum of 0.6 A.

S-DIAS has no intelligent master (manager).



# Table of Contents

|                                                                                                                             |           |
|-----------------------------------------------------------------------------------------------------------------------------|-----------|
| <b>1 Introduction</b>                                                                                                       | <b>4</b>  |
| 1.1 Target Group/Purpose of this Operating Manual                                                                           | 4         |
| 1.2 Important Reference Documentation                                                                                       | 4         |
| 1.3 Contents of Delivery                                                                                                    | 4         |
| <b>2 Basic Safety Directives</b>                                                                                            | <b>5</b>  |
| 2.1 Symbols Used                                                                                                            | 5         |
| 2.2 Disclaimer                                                                                                              | 6         |
| 2.3 General Safety Directives                                                                                               | 6         |
| 2.4 Software/Training                                                                                                       | 7         |
| <b>3 Standards and Directives</b>                                                                                           | <b>8</b>  |
| 3.1 Directives                                                                                                              | 8         |
| 3.1.1 EU Declaration of Conformity                                                                                          | 8         |
| 3.2 Safety-Relevant Parameters                                                                                              | 8         |
| <b>4 Type Plate</b>                                                                                                         | <b>9</b>  |
| <b>5 Technical Data</b>                                                                                                     | <b>10</b> |
| 5.1 Performance Data                                                                                                        | 10        |
| 5.2 Standard Configuration                                                                                                  | 11        |
| 5.3 Electrical Requirements                                                                                                 | 11        |
| 5.3.1 Module Supply (Input)                                                                                                 | 11        |
| 5.4 S-DIAS Bus Supply (Output)                                                                                              | 12        |
| 5.5 Miscellaneous                                                                                                           | 14        |
| 5.6 Environmental Conditions                                                                                                | 14        |
| <b>6 Mechanical Dimensions</b>                                                                                              | <b>15</b> |
| 6.1 Connector Layout                                                                                                        | 16        |
| 6.2 Status LEDs                                                                                                             | 16        |
| 6.3 Connectors                                                                                                              | 17        |
| 6.3.1 X1: USB Device 1.1 (Type Micro-B) (can be used with OTG cable as USB host, otherwise USB device for service purposes) | 17        |
| 6.3.2 X2 : Ethernet (Industrial Mini I/O)                                                                                   | 17        |
| 6.4 Applicable Connector Cables                                                                                             | 18        |
| 6.4.1 Ethernet                                                                                                              | 18        |

|                                            |           |
|--------------------------------------------|-----------|
| 6.5 Applicable Connectors .....            | 19        |
| 6.6 Label Field .....                      | 19        |
| 6.7 CAN Bus .....                          | 20        |
| 6.7.1 CAN Bus Station Number .....         | 20        |
| 6.7.2 Number of CAN Bus Participants ..... | 20        |
| 6.7.3 CAN Bus Data Transfer Rate .....     | 20        |
| 6.7.4 CAN Bus Termination .....            | 21        |
| 6.8 Note .....                             | 21        |
| 6.9 Shielding .....                        | 22        |
| 6.10 ESD Protection .....                  | 22        |
| <b>7 Strain Relief .....</b>               | <b>23</b> |
| <b>8 Process Diagram .....</b>             | <b>24</b> |
| <b>9 Status and Error Messages .....</b>   | <b>25</b> |
| <b>10 Application Exceptions .....</b>     | <b>33</b> |
| 10.1 Data Breakpoint .....                 | 33        |
| <b>11 Assembly/Installation .....</b>      | <b>34</b> |
| 11.1 Check Contents of Delivery .....      | 34        |
| 11.2 Mounting .....                        | 34        |
| <b>12 Transport/Storage .....</b>          | <b>36</b> |
| <b>13 Storage .....</b>                    | <b>37</b> |
| <b>14 Maintenance .....</b>                | <b>38</b> |
| 14.1 Service .....                         | 38        |
| 14.2 Repair .....                          | 38        |
| <b>15 Disposal .....</b>                   | <b>39</b> |

# 1 Introduction

## 1.1 Target Group/Purpose of this Operating Manual

This operating manual contains all information required for the operation of the product.

This operating manual is intended for:

- Project planners
- Technicians
- Commissioning engineers
- Machine operators
- Maintenance/test technicians

General knowledge of automation technology is required.

Further help and training information, as well as the appropriate accessories can be found on our website [www.sigmatek-automation.com](http://www.sigmatek-automation.com).

Our support team is happily available to answer your questions or assist you in case of any issues. Please see our website for our hotline number and business hours.

## 1.2 Important Reference Documentation

This and additional documents can be downloaded from our website or obtained through support.

## 1.3 Contents of Delivery

1x CP 102

## 2 Basic Safety Directives

### 2.1 Symbols Used

The following symbols are used in the operator documentation for warning and danger messages, as well as informational notes.

#### DANGER



**Danger** indicates that death or serious injury **will occur**, if the specified measures are not taken.

→ To avoid death or serious injuries, observe all guidelines.

**Danger** indique une situation dangereuse qui, faute de prendre les mesures adéquates, **entraînera** des blessures graves, voire mortelles.

→ Respectez toutes les consignes pour éviter des blessures graves, voire mortelles.

#### WARNING



**Warning** indicates that death or serious injury **can** occur, if the specified measures are not taken.

→ To avoid death or serious injuries, observe all guidelines.

**Avertissement** d'une situation dangereuse qui, faute de prendre les mesures adéquates, **entraînera** des blessures graves, voire mortelles.

→ Respectez toutes les consignes pour éviter des blessures graves, voire mortelles.

#### CAUTION



**Caution** indicates that moderate to slight injury **can** occur, if the specified measures are not taken.

→ To avoid moderate to slight injuries, observe all guidelines.

**Attention** indique une situation dangereuse qui, faute de prendre les mesures adéquates, **peut** entraîner des blessures assez graves ou légères.

→ Respectez toutes les consignes pour éviter des blessures graves, voire mortelles.

#### INFORMATION



#### INFORMATION

→ Provides important information on the product, handling or relevant sections of the documentation, which require particular attention.

## 2.2 Disclaimer

The contents of this operating manual were prepared with the greatest care. However, deviations cannot be ruled out. This operating manual is regularly checked and required corrections are included in the subsequent versions. The machine manufacturer is responsible for the proper assembly, as well as device configuration. The machine operator is responsible for safe handling, as well as proper operation.

The current operating manual can be found on our website. If necessary, contact our support.

Subject to technical changes, which improve the performance of the devices. The following operating manual is purely a product description. It does not guarantee properties under the warranty.

Please thoroughly read the corresponding documents and this operating manual before handling a product.

**SIGMATEK GmbH & Co KG is not liable for damages caused through, non-compliance with these instructions or applicable regulations.**

## 2.3 General Safety Directives

The Safety Directives in the other sections of this operating manual must be observed. These instructions are visually emphasized by symbols.

According to EU Directives, the operating manual is a component of a product. This operating manual must therefore be accessible in the vicinity of the machine since it contains important instructions. This operating manual should be included in the sale, rental or transfer of the product, or its online availability indicated.

Regarding the requirements for Safety and health connected to the use of machines, the manufacturer must perform a risk assessment in accordance with machine directives 2006/42/EG before introducing a machine to the market.

### INFORMATION



Operate the unit with devices and accessories approved by SIGMATEK only.



**CAUTION**

Handle the device with care and do not drop or let fall.  
Prevent foreign bodies and fluids from entering the device.  
The device must not be opened!

Manipulez l'appareil avec précaution et ne le laissez pas tomber.  
Empêchez les corps étrangers et les liquides de pénétrer dans l'appareil.  
L'appareil ne doit pas être ouvert!

If the device does not function as intended or has damage that could pose a danger, it must be replaced!

En cas de fonctionnement non conforme ou de dommages pouvant entraîner des risques, l'appareil doit être remplacé !

For your own safety and that of others, compliance with the environmental conditions is essential.

Pour votre propre sécurité et celle des autres, le respect des conditions environnementales est essentiel.

## 2.4 Software/Training

The application is created with the software LASAL CLASS 2 and LASAL SCREEN Editor.

Training for the LASAL development environment, with which the product can be configured, is provided. Information on our training schedule can be found on our website.

### 3 Standards and Directives

#### 3.1 Directives

The product was constructed in compliance with the following European Union directives and tested for conformity.

##### 3.1.1 EU Declaration of Conformity



#### EU Declaration of Conformity

The product CP 102 conforms to the following European directives:

- 2014/30/EU Electromagnetic Compatibility (EMC Directive)
- 2011/65/EU “Restricted use of certain hazardous substances in electrical and electronic equipment” (RoHS Directive)

The EU Conformity Declarations are provided on the SIGMATEK website. They can be found in the download area of the respective product.

#### 3.2 Safety-Relevant Parameters

|                                                                                                                              |           |
|------------------------------------------------------------------------------------------------------------------------------|-----------|
| Conditions                                                                                                                   | +55 °C    |
| Number of hours per year                                                                                                     | 8760      |
| MTBF                                                                                                                         | 107 years |
| MTTF <sub>D</sub>                                                                                                            | 213 years |
| The MTBF is a calculated value, which represents the failure probability and must not be confused with the product lifespan. |           |

4 Type Plate

The type plate provides information about the product's features. The type plate shown here is only an example.

|                                                                                                                                                                    |                                                                                                                                     |                                                                                                                                                                                                                                            |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Approbations                                                                                                                                                       |                                                                                                                                     | Standards                                                                                                                                                                                                                                  |
| <div>QR-Code</div> <div></div> <div>BJ: XXXX/XX</div> <div>S/N<br/>XXXXXXXX</div> | <div>Short Name</div> <div>Specifications</div> <div>FS: XXX.XX.XX</div> <div>FW: XXX</div> <div>LD: XX.X</div> <div>HW: X.XX</div> | <div>Electrical Ratings</div> <div> SIGMATEK</div> <div>Sigmathekstraße 1</div> <div>A-5112 Lamprechtshausen</div> <div>www.sigmatek-automation.com</div> |
| Article Number                                                                                                                                                     |                                                                                                                                     | Product Name                                                                                                                                                                                                                               |

- HW: Hardware version
- FS: Safety version number
- FW: Firmware version
- LD: Logic device version
- QR-Code: Serial number

## 5 Technical Data

### 5.1 Performance Data

|                                             |                                                                                                                                                                               |
|---------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Processor                                   | EDGE2 Technology                                                                                                                                                              |
| Processor cores                             | 1                                                                                                                                                                             |
| Addressable I/O/P modules                   | CAN participants: > 110<br>S-DIAS bus: 64 <sup>1)</sup>                                                                                                                       |
| Internal I/O                                | no                                                                                                                                                                            |
| Internal cache                              | 512 Kbytes L2 Cache                                                                                                                                                           |
| Internal program and data memory (DDR3 RAM) | 256 Mbytes                                                                                                                                                                    |
| Internal remnant data memory                | 2 Kbytes (one Flash block)                                                                                                                                                    |
| Internal storage device                     | NAND Flash, 256 Mbytes                                                                                                                                                        |
| Interfaces                                  | 1x USB OTG (host/device) (only for service purposes)<br>1x Ethernet<br>1x CAN<br>1x S-DIAS (without manager)                                                                  |
| Status display                              | no                                                                                                                                                                            |
| Status LEDs                                 | yes                                                                                                                                                                           |
| Real-time clock                             | no                                                                                                                                                                            |
|                                             | (After voltage is on, the date and time is set to the defined value 1.1 1970. The application must ensure that the actual time and date is set after the CPU start-up phase.) |
| Cooling                                     | passive (fanless)                                                                                                                                                             |

#### INFORMATION



<sup>1)</sup> The CP 102 can only supply the number of modules supported by the maximum output current (0.6 A) on the S-DIAS bus.

## 5.2 Standard Configuration

|          |    |                 |                        |
|----------|----|-----------------|------------------------|
| Ethernet | X2 | IP: 10.10.150.1 | Subnet mask: 255.0.0.0 |
|----------|----|-----------------|------------------------|

### INFORMATION



Problems can arise if a control is connected to an IP network, which contains modules that are not running with a SIGMATEK operating system. With such devices, Ethernet packets could be sent to the control with such a high frequency (i.e. broadcasts), that the high interrupt load could cause a real-time runtime error or runtime error. By configuring the packet filter (Firewall or Router) accordingly however, it is possible to connect a network with SIGMATEK hardware to a third-party network without triggering the problems mentioned above.

## 5.3 Electrical Requirements

### 5.3.1 Module Supply (Input)

|                                             |                                                        |                           |
|---------------------------------------------|--------------------------------------------------------|---------------------------|
| Supply voltage                              | +18-30 V DC, typically +24 V DC<br>UL: Class 2 or LVLC |                           |
| Current consumption of +24 V supply voltage | typically 100 mA <sup>2)</sup>                         | maximum 1 A <sup>1)</sup> |

### INFORMATION



For loading the internal capacitors, power consumption may be increased for a short time (in the microsecond range). This value is dependent on the input voltage and impedance of the power source.

### INFORMATION



For USA and Canada:

Only suitable for connection to secondary isolated power supply rated 24 V DC, class 2 or fuse rated max. 4 A in accordance with UL 248 shall be connected in the field between the supply source and device terminals.

If the equipment is used in a manner not specified by the manufacturer, the protection provided by the equipment may be impaired.


<sup>1)</sup> The current consumption is dependent on the connected load.

## 5.4 S-DIAS Bus Supply (Output)

|                                                                            |                                           |
|----------------------------------------------------------------------------|-------------------------------------------|
| Supply from S-DIAS bus                                                     | +5 V                                      |
| Current consumption on the S-DIAS bus (+5 V supply)                        | maximum 0.6 A <sup>1)</sup>               |
| Supply from S-DIAS bus                                                     | +24 V                                     |
| Current consumption on the S-DIAS bus (+24 V supply)                       | maximum 0.6 A <sup>1)</sup>               |
| USB host (OTG)<br>(can only be used with a USB stick for service purposes) | +5 V DC, maximum 200 mA (current limited) |

---

<sup>1)</sup> The current consumption is dependent on the connected load.



## 5.5 Miscellaneous


|                               |                   |                 |
|-------------------------------|-------------------|-----------------|
| Article number                | 20-004-102        |                 |
| Printed circuit board coating | no                |                 |
| Approvals                     | CE                | yes             |
|                               | UL                | cULus (E247993) |
|                               | Functional Safety | no              |
|                               | UKCA              | yes             |

## 5.6 Environmental Conditions

|                                       |                                                                                                                                            |                                             |
|---------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------|
| Storage temperature                   | -20 - +85 °C                                                                                                                               |                                             |
| Environmental temperature             | 0 ... +55 °C                                                                                                                               |                                             |
| Humidity                              | 0-95 %, non-condensing                                                                                                                     |                                             |
| Installation altitude above sea level | 0-2000 m without derating<br>> 2000 m up to a maximum of 5000 m with derating of the maximum environmental temperature by 0.5 °C per 100 m |                                             |
| Operating conditions                  | pollution degree 2                                                                                                                         |                                             |
| Noise emission                        | ≤ 70 dB                                                                                                                                    |                                             |
| EMC resistance                        | EN 61000-6-2 (industrial area)                                                                                                             |                                             |
| EMC noise generation                  | EN 61000-6-4 (industrial area)                                                                                                             |                                             |
| Vibration resistance                  | EN 60068-2-6                                                                                                                               | 3.5 mm from 5-8.4 Hz<br>1 g from 8.4-150 Hz |
| Shock resistance                      | EN 60068-2-27                                                                                                                              | 15 g (147.15 m/s²)                          |
| Protection type                       | EN 60529                                                                                                                                   | IP20<br>(not evaluated by UL)               |




# 6 Mechanical Dimensions



|              |                                |
|--------------|--------------------------------|
| Measurements | 12.5 x 104 x 72 mm (W x H x D) |
|--------------|--------------------------------|

6.1 Connector Layout



INFORMATION



The GND supply (X4: Pin 2 and Pin 3) is internally bridged. Only one GND pin (pin 2 or pin 3) is required to power the module. The bridged connections may be used for further looping of the GND supply. However, it must be taken into account that a total current of 6 A per connection is not exceeded by the forward looping!


6.2 Status LEDs

|     |       |        |                                                                                           |
|-----|-------|--------|-------------------------------------------------------------------------------------------|
| Run | green | ON     | from activation of the voltage supply until processing of the autoexec.lsl                |
|     |       |        | when the application is running (except when controlled differently via the application ) |
|     |       | BLINKS | in the CLI, while processing the autoexec.lsl until the application is running            |
|     |       |        | during installation of the operation system (starting from OS version 09.03.054)          |
|     |       | OFF    | when an error or reset occurs                                                             |
|     |       |        | can be set from the application (ON, BLINKING, OFF)                                       |

|                 |                                                     |        |                                          |
|-----------------|-----------------------------------------------------|--------|------------------------------------------|
| Status          | yellow                                              | OFF    | during start process                     |
|                 |                                                     |        | during RUN status (application running)  |
|                 |                                                     |        | when an error or reset occurs            |
|                 | can be set from the application (ON, BLINKING, OFF) |        |                                          |
| Error           | red                                                 | BLINKS | when an error or reset occurs            |
|                 |                                                     | OFF    | during start process                     |
|                 |                                                     |        | during RUN status (application running)  |
|                 | can be set from the application (ON, BLINKING, OFF) |        |                                          |
| Ethernet Link   | green                                               | ON     | connection between the two PHYs made     |
| Ethernet Active | yellow                                              | ON     | data is exchanged over the Ethernet bus  |
| CAN active      | yellow                                              | BLINKS | data is being exchanged                  |
| DC OK           | green                                               | ON     | module is supplied with a voltage > 18 V |


## 6.3 Connectors

### 6.3.1 X1: USB Device 1.1 (Type Micro-B) (can be used with OTG cable as USB host, otherwise USB device for service purposes)



| Pin | Function |
|-----|----------|
| 1   | +5 V     |
| 2   | D-       |
| 3   | D+       |
| 4   | ID       |
| 5   | GND      |

### 6.3.2 X2 : Ethernet (Industrial Mini I/O)



| Pin | Function |
|-----|----------|
| 1   | Tx+      |
| 2   | Tx-      |
| 3   | Rx+      |
| 4-5 | n.c.     |
| 6   | Rx-      |
| 7-8 | n.c.     |

n.c. = do not use

## 6.4 Applicable Connector Cables

### 6.4.1 Ethernet

| Cable type                                                                   | Length | Article number |
|------------------------------------------------------------------------------|--------|----------------|
| RJ45 on industrial Mini I/O Type 1, drag chain capable                       | 0.5 m  | 16-911-005     |
|                                                                              | 1 m    | 16-911-010     |
|                                                                              | 1.5 m  | 16-911-015     |
|                                                                              | 2 m    | 16-911-020     |
|                                                                              | 3 m    | 16-911-030     |
|                                                                              | 5 m    | 16-911-050     |
|                                                                              | 10 m   | 16-911-100     |
|                                                                              | 20 m   | 16-911-200     |
|                                                                              | 50 m   | 16-911-500     |
| Industrial Mini I/O Type 1 on Industrial Mini I/O Type 1, drag chain capable | 0.5 m  | 16-912-005     |
|                                                                              | 1 m    | 16-912-010     |
|                                                                              | 1.5 m  | 16-912-015     |
|                                                                              | 2 m    | 16-912-020     |
|                                                                              | 3 m    | 16-912-030     |
|                                                                              | 5 m    | 16-912-050     |
|                                                                              | 10 m   | 16-912-100     |
|                                                                              | 20 m   | 16-912-200     |

6.5 Applicable Connectors

- X1:** USB Type Micro-B OTG cable (host) or USB Type Micro-B to USB Type A cable (device) (no included in delivery)
- X2:** Industrial Mini I/O Plug Type 1 Lock Extended Version (not included in delivery)
- X3, X4:** Connectors with spring terminals (included in delivery)


The spring terminals are suited for the connection of ultrasonically compacted (ultrasonically welded) stranded wire.

Connection capacity:

|                                                                      |                                                       |
|----------------------------------------------------------------------|-------------------------------------------------------|
| Stripping length/sleeve length                                       | 10 mm                                                 |
| Mating direction                                                     | parallel to conductor axis or to circuit board        |
| Conductor cross section rigid                                        | 0.2-1.5 mm²                                           |
| Conductor cross section flexible                                     | 0.2-1.5 mm²                                           |
| Conductor cross section, ultrasonically compacted                    | 0.2-1.5 mm²                                           |
| Conductor cross section AWG/kcmil                                    | 24-16                                                 |
| Conductor cross section flexible with ferrule without plastic sleeve | 0.25-1.5 mm²                                          |
| Conductor cross section flexible with ferrule with plastic sleeve    | 0.25-0.75 mm² (reason for reducing d2 of the ferrule) |



6.6 Label Field



The labeling field is printed directly on the module.

## 6.7 CAN Bus

This section explains how to correctly configure the CAN bus. The following parameters must first be set: Station number and data transfer rate.

### 6.7.1 CAN Bus Station Number

Each CAN bus station is assigned its own station number. With this station number, data can be exchanged with other stations connected to the bus. In a CAN bus system however, each station number can only be assigned once!

### 6.7.2 Number of CAN Bus Participants

The maximum number of participants on the CAN bus depends on the cable length, termination resistance, data transfer rate and the drivers used in the participants. With a termination resistance of 120  $\Omega$ , at least 100 participants are possible.

### 6.7.3 CAN Bus Data Transfer Rate

Various data transfer rates (baud rates) can be set on the CAN bus. The longer the bus line is, the lower the data transfer rate that must be selected.

These values apply to the following cable: 120  $\Omega$  Twisted Pair.

| Value | Baud Rate  | Maximum Length |
|-------|------------|----------------|
| 0     | 615 kbit/s | 60 m           |
| 1     | 500 kbit/s | 80 m           |
| 2     | 250 kbit/s | 160 m          |
| 3     | 125 kbit/s | 320 m          |
| 4     | 100 kbit/s | 400 m          |
| 5     | 50 kbit/s  | 800 m          |
| 6     | 20 kbit/s  | 1200 m         |
| 7     | 1 Mbit/s   | 30 m           |


#### INFORMATION



For the CAN bus protocol: 1 kbit/s = 1 kBaud

### 6.7.4 CAN Bus Termination

In a CAN bus system, both end modules must be terminated. This is necessary to avoid transmission errors caused by reflections in the line.




Example

#### INFORMATION



The termination is made by placing a 120  $\Omega$  resistor between CAN A (LOW) and CAN B (HIGH).



### 6.8 Note

The input filters, which suppress noise signals, allow operation in harsh environmental conditions. A careful wiring method is also recommended to ensure error-free function.

**The following installation guidelines should be observed:**

- Avoid parallel connections between input lines and load-bearing circuits.
- Protective circuits for all relays (RC networks or free-wheeling diodes)
- Correct wiring to ground

#### INFORMATION



The ground bus should be connected to the control cabinet when possible!

The S-DIAS module CANNOT be connected/disconnected while voltage is applied!


## 6.9 Shielding

The CAN and Ethernet wiring must be shielded.

The low-ohm shielding must be either connected either at the entry to the control cabinet or directly before the CP 102 over a large surface (cable grommets, grounding clamps)!

Noise signals can therefore be prohibited from reaching the electronics and affecting the function.

To avoid compensating currents from the PE, which flow over the shielding the conductors, it is recommended that the system components have low Ohm and low impedance connections to one another.



## 6.10 ESD Protection


### CAUTION



Before any device is connected to or disconnected from the CP 102, the potential with ground must be equalized (by touching the control cabinet or ground terminal). Electrostatic loads (through clothing and shoes) can thereby be dissipated.



## 7 Strain Relief




### INFORMATION



The VARAN cable must be mounted close to the module (e.g. using a clamp)!  
No mechanical stress can be applied to the connection!

## 8 Process Diagram



## 9 Status and Error Messages

Status and error messages are shown in the status test of the LASAL CLASS software. POINTER or CHKSUM messages can also be shown on the screen.

| Number | Message        | Definition                                                                                                                                                                                                                                              | Cause/Solution                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
|--------|----------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 00     | <b>RUN RAM</b> | The user program is currently running in RAM. The display is not affected.                                                                                                                                                                              | Info                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| 01     | <b>RUN ROM</b> | The user program stored in the program memory module was loaded into the RAM and is currently running. The display is not affected.                                                                                                                     | Info                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| 02     | <b>RUNTIME</b> | The total time for all cyclic objects exceeds the maximum time; the time can be configured using 2 system variables: <ul style="list-style-type: none"> <li>■ Runtime: Remaining time</li> <li>■ SWRuntime: Preset value for runtime counter</li> </ul> | Solution: <ul style="list-style-type: none"> <li>■ Optimize the application's cyclic task.</li> <li>■ Use higher capacity CPU.</li> <li>■ Configure preset value</li> </ul>                                                                                                                                                                                                                                                                                                                                                                     |
| 03     | <b>POINTER</b> | Incorrect program pointers were detected before running the user program                                                                                                                                                                                | Possible Causes: <ul style="list-style-type: none"> <li>■ The program memory module is missing, not programmed or defective.</li> <li>■ The program in the user program memory (RAM) is not executable.</li> <li>■ The buffer battery has failed.</li> <li>■ The user program has overwritten a software error.</li> </ul> Solution: <ul style="list-style-type: none"> <li>■ Reprogram the memory module, if the error reoccurs exchange the module.</li> <li>■ Exchange the buffering battery</li> <li>■ Correct programming error</li> </ul> |
| 04     | <b>CHKSUM</b>  | An invalid checksum was detected before running the user program.                                                                                                                                                                                       | Cause/Solution: s. POINTER                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |

| Number | Message               | Definition                                                                                                                                                                                                                                                       | Cause/Solution                                                                                                                                                                                                                                                                                                                                                                                                                                        |
|--------|-----------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 05     | <b>WATCHDOG</b>       | The program was interrupted via the watchdog logic.                                                                                                                                                                                                              | <p>Possible Causes:</p> <ul style="list-style-type: none"> <li>■ User program interrupts blocked over a longer period of time (STI command forgotten).</li> <li>■ Programming error in a hardware interrupt.</li> <li>■ INB, OUTB, INW, OUTW instructions used incorrectly.</li> <li>■ The processor is defective.</li> </ul> <p>Solution:</p> <ul style="list-style-type: none"> <li>■ Correct programming error.</li> <li>■ Exchange CPU</li> </ul> |
| 06     | <b>GENERAL ERROR</b>  | General error<br>An error has occurred while stopping the application via the online interface.                                                                                                                                                                  | This error occurs only during the development of the operating system.                                                                                                                                                                                                                                                                                                                                                                                |
| 07     | <b>PROM DEFECT</b>    | An error has occurred while programming the memory module.                                                                                                                                                                                                       | <p>Causes:</p> <ul style="list-style-type: none"> <li>■ The program memory module is defective.</li> <li>■ The user program is too large.</li> <li>■ The program memory module is missing.</li> </ul> <p>Solution:</p> <ul style="list-style-type: none"> <li>■ Exchange the program memory module</li> </ul>                                                                                                                                         |
| 08     | <b>RESET</b>          | The CPU has received the reset signal and is waiting for further instructions.<br>The user program is not processed.                                                                                                                                             | Info                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| 09     | <b>WD DEFECT</b>      | The hardware monitoring circuit (watchdog logic) is defective.<br>After power-up, the CPU checks the watchdog logic function. If an error occurs during this test, the CPU deliberately enters an infinite loop from which no further instructions are accepted. | <p>Solution:</p> <ul style="list-style-type: none"> <li>■ Exchange CPU</li> </ul>                                                                                                                                                                                                                                                                                                                                                                     |
| 10     | <b>STOP</b>           | The program was stopped by the programming system.                                                                                                                                                                                                               |                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| 11     | <b>PROG BUSY</b>      | Reserved                                                                                                                                                                                                                                                         |                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| 12     | <b>PROGRAM LENGTH</b> | Reserved                                                                                                                                                                                                                                                         |                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| 13     | <b>PROG END</b>       | A memory module was successfully programmed.                                                                                                                                                                                                                     | Info                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| 14     | <b>PROG MEMO</b>      | The CPU is currently programming the memory module.                                                                                                                                                                                                              | Info                                                                                                                                                                                                                                                                                                                                                                                                                                                  |

| Number | Message               | Definition                                                                                                                                                               | Cause/Solution                                                                                                                                                                                                                                                                                                                      |
|--------|-----------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 15     | <b>STOP BRKPT</b>     | The CPU was stopped by a breakpoint in the program.                                                                                                                      | Info                                                                                                                                                                                                                                                                                                                                |
| 16     | <b>CPU STOP</b>       | The CPU was stopped by the programming software.                                                                                                                         | Info                                                                                                                                                                                                                                                                                                                                |
| 17     | <b>INT ERROR</b>      | The CPU has triggered a false interrupt and stopped the user program or has encountered an unknown instruction while running the program.                                | Causes: <ul style="list-style-type: none"> <li>■ A nonexistent operating system was used.</li> <li>■ Stack error (uneven number of PUSH and POP instructions).</li> <li>■ The user program was interrupted by a software error.</li> </ul> Solution: <ul style="list-style-type: none"> <li>■ Correct programming error.</li> </ul> |
| 18     | <b>SINGLE STEP</b>    | The CPU is in single step mode and is waiting for further instructions.                                                                                                  | Info                                                                                                                                                                                                                                                                                                                                |
| 19     | <b>READY :</b>        | A module or project has been sent to the CPU and it is ready to run the program.                                                                                         | Info                                                                                                                                                                                                                                                                                                                                |
| 20     | <b>LOAD</b>           | The program is stopped and the CPU is currently receiving a new module or project.                                                                                       | Info                                                                                                                                                                                                                                                                                                                                |
| 21     | <b>INVALID MODULE</b> | The CPU has received a module that does not belong to the project.                                                                                                       | Solution: <ul style="list-style-type: none"> <li>■ Recompile and download the entire project</li> </ul>                                                                                                                                                                                                                             |
| 22     | <b>MEMORY FULL</b>    | The operating system memory (heap) is too small. No memory could be reserved while calling an internal function or an interface function is called from the application. | Causes: <ul style="list-style-type: none"> <li>■ Memory is only allocated but not released.</li> </ul> Solution: <ul style="list-style-type: none"> <li>■ Clear memory</li> </ul>                                                                                                                                                   |
| 23     | <b>NOT LINKED</b>     | When starting the CPU, a missing module or a module that does not belong to the project was detected.                                                                    | Solution: <ul style="list-style-type: none"> <li>■ Recompile and download the entire project</li> </ul>                                                                                                                                                                                                                             |
| 24     | <b>DIV BY 0</b>       | A division error has occurred.                                                                                                                                           | Possible Causes: <ul style="list-style-type: none"> <li>■ Division by 0.</li> <li>■ The result of a division does not fit in the result register.</li> </ul> Solution: <ul style="list-style-type: none"> <li>■ Correct programming error.</li> </ul>                                                                               |
| 25     | <b>DIAS ERROR</b>     | While accessing a DIAS module, an error has occurred.                                                                                                                    | Hardware problem                                                                                                                                                                                                                                                                                                                    |
| 26     | <b>WAIT</b>           | The CPU is busy.                                                                                                                                                         | Info                                                                                                                                                                                                                                                                                                                                |

| Number | Message             | Definition                                                                      | Cause/Solution                                                                                           |
|--------|---------------------|---------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------|
| 27     | OP PROG             | The operating system is currently being reprogrammed.                           | Info                                                                                                     |
| 28     | OP INSTALLED        | The operating system has been reinstalled.                                      | Info                                                                                                     |
| 29     | OS TOO LONG         | The operating system cannot be loaded; too little memory.                       | Restart, report error to SIGMATEK.                                                                       |
| 30     | NO OPERATING SYSTEM | Boot loader message, no operating system found in RAM.                          | Restart, report error to SIGMATEK.                                                                       |
| 31     | SEARCH FOR OS       | The boot loader is searching for the operating system in RAM.                   | Restart, report error to SIGMATEK.                                                                       |
| 32     | NO DEVICE           | Reserved                                                                        |                                                                                                          |
| 33     | UNUSED CODE         | Reserved                                                                        |                                                                                                          |
| 34     | MEM ERROR           | The operating system loaded does not match the hardware configuration.          | Solution:<br><ul style="list-style-type: none"> <li>Use the correct operating system version</li> </ul>  |
| 35     | MAX IO              | Reserved                                                                        |                                                                                                          |
| 36     | MODULE LOAD ERROR   | The LASAL Module or project cannot be loaded.                                   | Solution:<br><ul style="list-style-type: none"> <li>Recompile and download the entire project</li> </ul> |
| 37     | BOOTIMAGE FAILURE   | A general error has occurred while loading the operating system.                | Contact SIGMATEK                                                                                         |
| 38     | APPLMEM ERROR       | An error has occurred in the application memory (user heap).                    | Solution:<br><ul style="list-style-type: none"> <li>Correct allocated memory access error</li> </ul>     |
| 39     | OFFLINE             | This error does not occur in the control.                                       | This error code is used in the programming system to show that there is no connection to the control.    |
| 40     | APPL LOAD           | Reserved                                                                        |                                                                                                          |
| 41     | APPL SAVE           | Reserved                                                                        |                                                                                                          |
| 44     | VARAN MANAGER ERROR | An error number was entered in the VARAN manager and stopped the program.       | Solution:<br><ul style="list-style-type: none"> <li>Read LogFile</li> </ul>                              |
| 45     | VARAN ERROR         | A required VARAN client was disconnected or a communication error has occurred. | Solution:<br><ul style="list-style-type: none"> <li>Read LogFile</li> <li>Error tree</li> </ul>          |

| Number | Message                       | Definition                                                                                                                                                                                        | Cause/Solution                                                                                                                                                                                                                                                                                             |
|--------|-------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 46     | <b>APPL-LOAD-ERROR</b>        | An error has occurred while loading the application.                                                                                                                                              | Cause: <ul style="list-style-type: none"> <li>■ Application was deleted.</li> </ul> Solution: <ul style="list-style-type: none"> <li>■ Reload the application into the control.</li> </ul>                                                                                                                 |
| 47     | <b>APPL-SAVE-ERROR</b>        | An error has occurred while attempting to save the application.                                                                                                                                   |                                                                                                                                                                                                                                                                                                            |
| 50     | <b>ACCESS-EXCEPTION-ERROR</b> | Read or write access of a restricted memory area. (I.e. writing to the NULL pointer).                                                                                                             | Solution: <ul style="list-style-type: none"> <li>■ Correct application errors</li> </ul>                                                                                                                                                                                                                   |
| 51     | <b>BOUND EXCEEDED</b>         | An exception error has occurred while accessing arrays. The memory area was overwritten by accessing an invalid element.                                                                          | Solution: <ul style="list-style-type: none"> <li>■ Correct application errors</li> </ul>                                                                                                                                                                                                                   |
| 52     | <b>PRIVILEGED INSTRUCTION</b> | An unauthorized instruction for the current CPU level was given. For example, setting the segment register.                                                                                       | Cause: <ul style="list-style-type: none"> <li>■ The application has overwritten the application program code.</li> </ul> Solution: <ul style="list-style-type: none"> <li>■ Correct application errors</li> </ul>                                                                                          |
| 53     | <b>FLOATING POINT ERROR</b>   | An error has occurred during a floating-point operation.                                                                                                                                          |                                                                                                                                                                                                                                                                                                            |
| 60     | <b>DIAS-RISC-ERROR</b>        | Error from the Intelligent DIAS Master.                                                                                                                                                           | Restart, report error to SIGMATEK.                                                                                                                                                                                                                                                                         |
| 64     | <b>INTERNAL ERROR</b>         | An internal error has occurred, all applications are stopped.                                                                                                                                     | Restart, report error to SIGMATEK.                                                                                                                                                                                                                                                                         |
| 65     | <b>FILE ERROR</b>             | An error has occurred during a file operation.                                                                                                                                                    |                                                                                                                                                                                                                                                                                                            |
| 66     | <b>DEBUG ASSERTION FAILED</b> | Internal error                                                                                                                                                                                    | Restart, report error to SIGMATEK.                                                                                                                                                                                                                                                                         |
| 67     | <b>REALTIME RUNTIME</b>       | The total duration of all real-time objects exceeds the maximum time; the time cannot be configured.<br>2 ms for 386 CPUs<br>1 ms for all other CPUs                                              | Solution: <ul style="list-style-type: none"> <li>■ Optimize the application's real-time task (RtWork).</li> <li>■ Reduce the clock time for the real-time task of all objects.</li> <li>■ Correct application errors</li> <li>■ CPU is overloaded in real-time =&gt; use a higher capacity CPU.</li> </ul> |
| 68     | <b>BACKGROUND RUNTIME</b>     | The total time for all background objects exceeds the maximum time; the time can be configured using 2 system variables: -<br>BTRuntime: -SWBTRuntime: pre-selected value for the runtime counter | Solution: <ul style="list-style-type: none"> <li>■ Optimize the application's background task (background)</li> <li>■ Use higher capacity CPU</li> <li>■ Set SWBTRuntime correctly</li> </ul>                                                                                                              |

| Number | Message        | Definition                                                                                      | Cause/Solution                                                                                                                                                                                                                                                                                                                                                                      |
|--------|----------------|-------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 70     | C-DIAS ERROR   | A connection error with a C-DIAS module has occurred.                                           | Cause: <ul style="list-style-type: none"> <li>■ The cause of the error is documented in the log file</li> </ul> Solution: <ul style="list-style-type: none"> <li>■ This depends on the cause</li> </ul>                                                                                                                                                                             |
| 72     | S-DIAS ERROR   | A connection error with an S-DIAS module has occurred.                                          | Possible Causes: <ul style="list-style-type: none"> <li>■ Real network does not match the project</li> <li>■ S-DIAS client is defective</li> </ul> Solution: <ul style="list-style-type: none"> <li>■ Analyze log file</li> </ul>                                                                                                                                                   |
| 75     | SRAM ERROR     | An error occurred while initializing, reading or writing SRAM data.                             | Possible Causes: <ul style="list-style-type: none"> <li>■ SRAM configured incorrectly</li> <li>■ Battery for powering the internal program memory is empty</li> </ul> Solution: <ul style="list-style-type: none"> <li>■ Analyze log file (Event00.log, Event19.log)</li> <li>■ Check configuration</li> <li>■ Exchange battery for powering the internal program memory</li> </ul> |
| 95     | USER DEFINED 0 | User-definable code.                                                                            |                                                                                                                                                                                                                                                                                                                                                                                     |
| 96     | USER DEFINED 1 | User-definable code.                                                                            |                                                                                                                                                                                                                                                                                                                                                                                     |
| 97     | USER DEFINED 2 | User-definable code.                                                                            |                                                                                                                                                                                                                                                                                                                                                                                     |
| 98     | USER DEFINED 3 | User-definable code.                                                                            |                                                                                                                                                                                                                                                                                                                                                                                     |
| 99     | USER DEFINED 4 | User-definable code.                                                                            |                                                                                                                                                                                                                                                                                                                                                                                     |
| 100    | C_INIT         | Initialization start; the configuration is run.                                                 |                                                                                                                                                                                                                                                                                                                                                                                     |
| 101    | C_RUNRAM       | The LASAL project was successfully started from RAM.                                            |                                                                                                                                                                                                                                                                                                                                                                                     |
| 102    | C_RUNROM       | The LASAL project was successfully started from ROM.                                            |                                                                                                                                                                                                                                                                                                                                                                                     |
| 103    | C_RUNTIME      |                                                                                                 |                                                                                                                                                                                                                                                                                                                                                                                     |
| 104    | C_READY        | The CPU is ready for operation.                                                                 |                                                                                                                                                                                                                                                                                                                                                                                     |
| 105    | C_OK           | The CPU is ready for operation.                                                                 |                                                                                                                                                                                                                                                                                                                                                                                     |
| 106    | C_UNKNOWN_CID  | An unknown object from a stand-alone or embedded object, or an unknown base class was detected. |                                                                                                                                                                                                                                                                                                                                                                                     |



| Number | Message          | Definition                                                                            | Cause/Solution |
|--------|------------------|---------------------------------------------------------------------------------------|----------------|
| 107    | C_UNKNOWN_CONSTR | The operating system class cannot be created; the operating system is probably wrong. |                |
| 108    | C_UNKNOWN_OBJECT | Indicates an unknown object in an interpreter program; more the one DCC080 object.    |                |
| 109    | C_UNKNOWN_CHNL   | The hardware module number is greater than 60.                                        |                |
| 110    | C_WRONG_CONNECT  | No connection to the required channels.                                               |                |
| 111    | C_WRONG_ATTR     | Wrong server attributes.                                                              |                |
| 112    | C_SYNTAX_ERROR   | Non-specific error. Recompile and download all project sections.                      |                |
| 113    | C_NO_FILE_OPEN   | An attempt was made to open an unknown table.                                         |                |
| 114    | C_OUTOF_NEAR     | Memory allocation failed                                                              |                |
| 115    | C_OUT OF_FAR     | Memory allocation failed                                                              |                |
| 116    | C_INCOMAPTIBLE   | An object with the same name already exists but has a different class.                |                |
| 117    | C_COMPATIBLE     | An object with the same name and class exists but must be updated.                    |                |
| 224    | LINKING          | The application is currently linking.                                                 |                |
| 225    | LINKING ERROR    | An error has occurred while linking.                                                  |                |
| 226    | LINKING DONE     | Linking is complete.                                                                  |                |
| 230    | OP BURN          | The operating system is currently being burned into the Flash memory.                 |                |
| 231    | OP BURN FAIL     | An error has occurred while burning the operating system.                             |                |
| 232    | OP INSTALL       | The operating system is currently being installed.                                    |                |
| 240    | USV-WAIT         | The power supply was disconnected; the UPS is active. The system is shutdown.         |                |
| 241    | REBOOT           | The operating system is restarted.                                                    |                |

| Number | Message          | Definition                  | Cause/Solution |
|--------|------------------|-----------------------------|----------------|
| 242    | LSL SAVE         |                             |                |
| 243    | LSL LOAD         |                             |                |
| 252    | CONTINUE         |                             |                |
| 253    | PRERUN           | The application is started. |                |
| 254    | PRERESET         | The application is ended.   |                |
| 255    | CONNECTION BREAK |                             |                |

## 10 Application Exceptions

Do not store, modify or write on the Flash from the user program.

### 10.1 Data Breakpoint

This CPU does not support the data breakpoint feature.

## 11 Assembly/Installation

### 11.1 Check Contents of Delivery

Ensure that the contents of the delivery are complete and intact. See chapter 1.3 Contents of Delivery.

#### INFORMATION




On receipt and before initial use, check the device for damage. If the device is damaged, contact our customer service and do not install the device in your system.


Damaged components can disrupt or damage the system.

### 11.2 Mounting

The S-DIAS modules are designed for installation into the control cabinet. To mount the modules, a DIN-rail is required. The DIN rail must establish a conductive connection with the back wall of the control cabinet. The individual S-DIAS modules are mounted on the DIN rail as a block and secured with latches. The functional ground connection from the module to the DIN rail is made via the grounding lug on the back of the S-DIAS modules. The modules must be mounted horizontally (module label up) with sufficient clearance between the ventilation slots of the S-DIAS module blocks and nearby components and/or the control cabinet wall. This is necessary for optimal cooling and air circulation to ensure proper function up to the maximum operating temperature.



Recommended minimum distances between the S-DIAS modules and the surrounding components or control cabinet wall:



a, b, c ... distances in mm (inches)

## 12 Transport/Storage

This device contains sensitive electronics. During transport and storage, high mechanical stress must therefore be avoided.

For storage and transport, the same values for humidity and vibration as for operation must be maintained!

Temperature and humidity fluctuations may occur during transport. Ensure that no moisture condenses in or on the device, by allowing the device to acclimate to the room temperature while turned off.

When sent, the device should be transported in the original packaging if possible. Otherwise, packaging should be selected that sufficiently protects the product from external mechanical influences. Such as cardboard filled with air cushioning.

## 13 Storage

When not in use, store the device according to the storage conditions. See chapter 12 Transport/Storage.

### INFORMATION



During storage, ensure that all protective covers (if available) are placed correctly, so that no contamination, foreign bodies or fluids enter the device.

## 14 Maintenance

During maintenance as well as servicing, observe the safety instructions from chapter 2 Basic Safety Directives.

### 14.1 Service

This product was constructed for low-maintenance operation.

### 14.2 Repair

In the event of a defect/repair, send the device with a detailed error description to the address listed at the beginning of this document.

For transport conditions, see chapter 12 Transport/Storage.



## 15 Disposal



### INFORMATION

Should you need to dispose of the device, the national regulations for disposal must be followed.

The device appliance must not be disposed of as household waste.



## Changes Chart

| Change date | Affected page(s) | Chapter                         | Note                                                                           |
|-------------|------------------|---------------------------------|--------------------------------------------------------------------------------|
| 30.01.2015  | 21               | 6.8 Note                        | Note regarding connecting/disconnecting the S-DIAS module under voltage added. |
| 26.03.2015  | 19               | 6.5 Applicable Connectors       | Added connections                                                              |
| 04.05.2015  | 10               | 5.1 Performance Data            | Note added                                                                     |
| 15.06.2015  | 20               | 6.7 CAN Bus                     | Transmission speed – note added                                                |
| 15.10.2015  | 11               | 5.3 Electrical Requirements     | Table split                                                                    |
| 22.10.2015  | 11               | 5.3.1 Module Supply (Input)     | Note added instead of table column switch-on current                           |
| 12.11.2015  | 10               | 5.1 Performance Data            | Sentences deleted                                                              |
|             | 33               | 10 Application Exceptions       |                                                                                |
| 12.02.2016  | 10               | 5 Technical Data                | Adjusted and graphics added                                                    |
|             | 21               | 6.8 Note                        | ESD protection and Shielding added                                             |
| 19.04.2016  | 10               | 5.1 Performance Data            | Table updated                                                                  |
| 28.04.2016  | 34               | 11 Assembly/Installation        | Graphics distances                                                             |
| 15.12.2016  | 16               | 6.2 Status LEDs                 | Run / green / blinks extended                                                  |
| 17.08.2017  | 14               | 5.6 Environmental Conditions    | Pollution degree sleeve length added                                           |
|             | 19               | 6.5 Applicable Connectors       | Added info regarding ultrasonically welded strands                             |
| 03.10.2017  | 18               | 6.4 Applicable Connector Cables | RJ45 on industrial Mini I/O Type 1, drag chain capable: 50 m cable added       |
| 18.10.2017  | 19               | 6.6 Label Field                 | Added chapter                                                                  |
|             | 34               | 11 Assembly/Installation        | Graphic replaced                                                               |
| 19.06.2018  | 11               | 5.3.1 Module Supply (Input)     | Note UL conditions                                                             |
| 20.09.2018  | 16               | 6.1 Connector Layout            | Note added                                                                     |
| 16.04.2019  | 8                | 3.2 Safety-Relevant Parameters  | Chapter added                                                                  |
| 04.11.2020  | 34               | 11 Assembly/Installation        | Expansion functional ground connection                                         |
| 06.12.2022  | 14               | 5.5 Miscellaneous               | UKCA conformity                                                                |
| 20.04.2023  | 16               | 6.1 Connector Layout            | Info box corrected                                                             |
| 26.07.2023  |                  | Document                        | General chapters added, design                                                 |
| 22.07.2026  | 8                | 3.2 Safety-Relevant Parameters  | Values deleted                                                                 |