

AI 088-1

S-DIAS Analog Input Module

INSTRUCTION MANUAL

Article number:	20-009-088-1-E
Date of creation:	20.09.2017
Version date:	14.01.2026



Publisher:

SIGMATEK GmbH & Co KG
A-5112 Lamprechtshausen
Tel.: +43/6274/4321
Fax: +43/6274/4321-18

Email: office@sigmatek.at
www.sigmathek-automation.com

All rights reserved. No part of this work may be reproduced, edited using an electronic system, duplicated or distributed in any form (print, photocopy, microfilm or in any other process) without express permission.

We reserve the right to make changes in the content without notice. SIGMATEK GmbH & Co KG is not responsible for technical or printing errors in this handbook and assumes no responsibility for damages that occur through its use.

S-DIAS Analog Input Module

AI 088-1**8 thermal element inputs****2 KTY temperature sensor inputs****1 KTY temperature sensor**

The S-DIAS Analog Input Module AI 088-1 has eight thermal element inputs for all conventional thermal element types. Two inputs for KTY temperature sensors are also provided or starting with hardware version HW3.0 and firmware version FW2.0, additional temperature sensors for thermocouple compensation are integrated into the module.




Table of Contents

1 Introduction	4
1.1 Target Group/Purpose of this Operating Manual	4
1.2 Important Reference Documentation	4
1.3 Contents of Delivery	4
2 Basic Safety Directives	5
2.1 Symbols Used	5
2.2 Disclaimer	6
2.3 General Safety Directives	6
2.4 Software/Training	7
3 Standards and Directives	8
3.1 Directives	8
3.1.1 EU Declaration of Conformity	8
4 Type Plate	9
5 Technical Data	10
5.1 Thermocouple Input Specifications	10
5.2 Temperature Inputs for Thermocoupling Compensation Specifications	10
5.2.1 Measurement Range Voltage	11
5.2.2 Measuring Ranges Thermocouples	11
5.3 Electrical Requirements	11
5.4 Miscellaneous	13
5.5 Environmental Conditions	13
6 Mechanical Dimensions	14
7 Connector Layout	15
7.1 Status LEDs	15
7.2 Applicable Connectors	16
7.3 Label Field	17
8 Wiring	18
8.1 Wiring Example	18
8.2 Note	19
8.3 Measuring Temperature with Thermal Elements	19
8.4 Connecting the Thermoelement to the Control	20

8.5 Connecting the Thermo Element over an Intermediate Coupling without Equalization Cable	21
9 Assembly/Installation	22
9.1 Check Contents of Delivery	22
9.2 Mounting	22
10 Transport/Storage	24
11 Storage	25
12 Maintenance	26
12.1 Service	26
12.2 Repair	26
13 Disposal	27
14 Addressing	28
14.1 Address Mapping Overview	28
15 Supported Cycle Times	31
15.1 Cycle Times below 1 ms (in μ s)	31
15.2 Cycle Times equal to or higher than 1 ms (in ms)	31
16 Hardware Class	33
AI088_1	34

1 Introduction

1.1 Target Group/Purpose of this Operating Manual

This operating manual contains all information required for the operation of the product.

This operating manual is intended for:

- Project planners
- Technicians
- Commissioning engineers
- Machine operators
- Maintenance/test technicians

General knowledge of automation technology is required.

Further help and training information, as well as the appropriate accessories can be found on our website www.sigmatek-automation.com.

Our support team is happily available to answer your questions.
Please see our website for our hotline number and business hours.

1.2 Important Reference Documentation

This and additional documents can be downloaded from our website or obtained through support.

1.3 Contents of Delivery

1x AI 088-1

2 Basic Safety Directives

2.1 Symbols Used

The following symbols are used in the operator documentation for warning and danger messages, as well as informational notes.

DANGER



Danger indicates that death or serious injury **will occur**, if the specified measures are not taken.

→ To avoid death or serious injuries, observe all guidelines.

Danger indique une situation dangereuse qui, faute de prendre les mesures adéquates, **entraînera** des blessures graves, voire mortelles.

→ Respectez toutes les consignes pour éviter des blessures graves, voire mortelles.

WARNING



Warning indicates that death or serious injury **can** occur, if the specified measures are not taken.

→ To avoid death or serious injuries, observe all guidelines.

Avertissement d'une situation dangereuse qui, faute de prendre les mesures adéquates, **entraînera** des blessures graves, voire mortelles.

→ Respectez toutes les consignes pour éviter des blessures graves, voire mortelles.

CAUTION



Caution indicates that moderate to slight injury **can** occur, if the specified measures are not taken.

→ To avoid moderate to slight injuries, observe all guidelines.

Attention indique une situation dangereuse qui, faute de prendre les mesures adéquates, **peut** entraîner des blessures assez graves ou légères.

→ Respectez toutes les consignes pour éviter des blessures graves, voire mortelles.

INFORMATION



INFORMATION

→ Provides important information on the product, handling or relevant sections of the documentation, which require particular attention.

2.2 Disclaimer

The contents of this operating manual were prepared with the greatest care. However, deviations cannot be ruled out. This operating manual is regularly checked and required corrections are included in the subsequent versions. The machine manufacturer is responsible for the proper assembly, as well as device configuration. The machine operator is responsible for safe handling, as well as proper operation.

The current operating manual can be found on our website. If necessary, contact our support.

Subject to technical changes, which improve the performance of the devices. The following operating manual is purely a product description. It does not guarantee properties under the warranty.

Please thoroughly read the corresponding documents and this operating manual before handling a product.

SIGMATEK GmbH & Co KG is not liable for damages caused through, non-compliance with these instructions or applicable regulations.

2.3 General Safety Directives

The Safety Directives in the other sections of this operating manual must be observed. These instructions are visually emphasized by symbols.

According to EU Directives, the operating manual is a component of a product. This operating manual must therefore be accessible in the vicinity of the machine since it contains important instructions. This operating manual should be included in the sale, rental or transfer of the product, or its online availability indicated.

Regarding the requirements for Safety and health connected to the use of machines, the manufacturer must perform a risk assessment in accordance with machine directives 2006/42/EG before introducing a machine to the market.

INFORMATION



Operate the unit with devices and accessories approved by SIGMATEK only.

CAUTION

Handle the device with care and do not drop or let fall.
Prevent foreign bodies and fluids from entering the device.
The device must not be opened!

Manipulez l'appareil avec précaution et ne le laissez pas tomber.
Empêchez les corps étrangers et les liquides de pénétrer dans l'appareil.
L'appareil ne doit pas être ouvert!

If the device does not function as intended or has damage that could pose a danger, it must be replaced!

En cas de fonctionnement non conforme ou de dommages pouvant entraîner des risques, l'appareil doit être remplacé !

For your own safety and that of others, compliance with the environmental conditions is essential.

Pour votre propre sécurité et celle des autres, le respect des conditions environnementales est essentiel.

2.4 Software/Training

The application is created with the software LASAL CLASS 2 and LASAL SCREEN Editor.

Training for the LASAL development environment, with which the product can be configured, is provided. Information on our training schedule can be found on our website.

3 Standards and Directives

3.1 Directives

The product was constructed in compliance with the following European Union directives and tested for conformity.

3.1.1 EU Declaration of Conformity



EU Declaration of Conformity

The product AI 088-1 conforms to the following European directives:

- 2014/30/EU Electromagnetic Compatibility (EMC Directive)
- 2011/65/EU “Restricted use of certain hazardous substances in electrical and electronic equipment” (RoHS Directive)

The EU Conformity Declarations are provided on the SIGMATEK website. They can be found in the download area of the respective product.

4 Type Plate

The type plate provides information about the product's features. The type plate shown here is only an example.

Approbations		Standards
QR-Code  BJ: XXXX/XX S/N XXXXXXXX	Short Name Specifications FS: XXX.XX.XX FW: XXX LD: XX.X HW: X.XX	Electrical Ratings  SIGMATEK Sigmathekstraße 1 A-5112 Lamprechtshausen www.sigmatek-automation.com
Article Number		Product Name

HW: Hardware version
FS: Safety version number
FW: Firmware version
LD: Logic device version
QR-Code: Serial number

5 Technical Data

5.1 Thermocouple Input Specifications

Number of channels	8	
Measurement range	see the following table for measuring ranges of thermocouples	
Resolution converter	16 bits	
Conversion time per channel	1 ms	
Common mode range	± 10 V	
Input resistance	2 M Ω	
Cable break monitoring	yes	
Measuring current for cable break monitoring	typically 3 μ A ¹⁾	
Overvoltage protection	265 V AC	
Input filter hardware	typically 2 Hz	low-pass 3 rd order
Input filter software	50 Hz/60 Hz	
Measurement precision	± 0.7 % of the maximum measurement value ²⁾	

5.2 Temperature Inputs for Thermocoupling Compensation Specifications

Number of channels	2	
Sensor type	KTY10-62 or KTY11-62 (up to HW 3.40, no longer available) KTY11-62 replacement sensor (from HW 3.50)	
Measurement range	-20 ... +80 °C	
Measurement value	-200 ... +800	
	if the input is open/short-circuited, the hardware class returns -2147483632	
Resolution converter	16 bits	
Conversion time per channel	1 ms	
Sensor current	typically 0.3 mA at 25 °C	
Cable break monitoring	yes	
Short-circuit monitoring	yes	
Input filter hardware	typically 2 Hz	low-pass 3 rd order
Measurement precision	± 0.7 % of the maximum measured value	

¹⁾ The conductor resistance of the thermocouples causes a measurement error in connection with the measuring current for cable break monitoring.

²⁾ Does not include the measurement error of the temperature measurement of the terminal point.

5.2.1 Measurement Range Voltage

Type	Voltage range	Measured value ¹⁾
1	0-50 mV	0-50000

5.2.2 Measuring Ranges Thermocouples

Type	Thermocouple	Measurement range	Measured value ²⁾	Measurement error ³⁾
J	Fe-CuNi	-10 ... +850 °C (-0.501 ... 48.715 mV)	-100 ... 8500	0.0062 %/Ω
K	NiCr-Ni	-40 ... +1200 °C (-1.527 ... 48.838 mV)	-400 ... 12000	0.0061 %/Ω
T	Cu-CuNi	-40 ... +400 °C (-1.475 ... 20.872 mV)	-400 ... 4000	0.0144 %/Ω
E	NiCr-CuNi	0 ... +640 °C (0 ... 48.313 mV)	0 ... 6400	0.0062 %/Ω
N	NiCrSi-NiSi	-80 ... +1300 °C (-1.972 ... 47.513 mV)	-800 ... 13000	0.0063 %/Ω
S	Pt10Rh-Pt	-50 ... +1768 °C (-0.236 ... 18.693 mV)	-500 ... 17680	0.0160 %/Ω
R	Pt13Rh-Pt	-50 ... +1768 °C (-0.226 ... 21.101 mV)	-500 ... 17680	0.0142 %/Ω
B	Pt30Rh-Pt6Rh	0 ... +1820 °C (0 ... 13.820 mV)	0 ... 18200	0.0217 %/Ω
L	Fe-CuNi	0 ... +840 °C (0 ... 48.943 mV)	0 ... 8400	0.0061 %/Ω
U	Cu-CuNi	0 ... +600 °C (0 ... 34.309 mV)	0 ... 6000	0.0087 %/Ω

5.3 Electrical Requirements

Voltage supply from S-DIAS bus	+5 V	
Current consumption on the S-DIAS bus (+5 V supply)	typically 62 mA	maximum 68 mA
Voltage supply from S-DIAS bus	+24 V	
Current consumption on the S-DIAS bus (+24 V supply)	typically 75 mA	maximum 90 mA

INFORMATION




If this S-DIAS module is used on an S-DIAS supply module with several S-DIAS modules, the total currents of the S-DIAS modules used must be determined and checked.
 The total current of the +24 V supply must not exceed 1.6 A!
 The total current of the +5 V supply must not exceed 1.6 A!
 The power consumption information can be found in the module-specific technical documentation under "Electrical Requirements".

¹⁾ When the input is open, the hardware class returns -2147483632.

²⁾ When the input is open, the hardware class returns -2147483632.

³⁾ Measurement error due to the lead resistance of the thermocouples, in relation to the measuring range.




5.4 Miscellaneous

Article number	20-009-088-1	
Printed circuit board coating	no	
Approvals	CE	yes
	UL	cULus (E247993)
	Functional Safety	no
	UKCA	no


5.5 Environmental Conditions

Storage temperature	-20 ... +85 °C	
Environmental temperature	0 ... +60 °C	
Humidity	0-95 %, non-condensing	
Installation altitude above sea level	0-2000 m without derating > 2000 m up to a maximum of 5000 m with derating of the maximum environmental temperature by 0.5 °C per 100 m	
Operating conditions	pollution degree 2	
Noise emission	≤ 70 dB	
EMC resistance	EN 61000-6-2 (industrial area)	
EMC noise generation	EN 61000-6-4 (industrial area)	
Vibration resistance	EN 60068-2-6	3.5 mm von 5-8.4 Hz 1 g von 8.4-150 Hz
Shock resistance	EN 60068-2-27	15 g (147.15 m/s ²)
Protection type	EN 60529/NEMA 250	IP20/Type1

6 Mechanical Dimensions



7 Connector Layout



The temperature sensors for the terminal point compensation (KTY1, KTY2 or from HW3.0 and from FW2.0 module-internal temperature sensors) can be set separately for each thermocouple input using software. If the KTY temperature inputs are not required for terminal point compensation, they can also be used as independent temperature inputs.

7.1 Status LEDs

Module Status	green	ON	module active
		OFF	no supply available
		BLINKING (5 Hz)	no communication
User	yellow	ON	can be set from the application
		OFF	(e.g. the module LED can be set to blinking through the visualization so that the module is easily found in the control cabinet)
		BLINKING (2 Hz)	
		BLINKING (4 Hz)	

7.2 Applicable Connectors


X1-X4: Connectors with spring terminals gold-plated(included in delivery)

X5: Connectors with spring terminals tin-plated(included in delivery)


The spring terminals are suited for the connection of ultrasonically compacted (ultrasonically welded) stranded wire.

Connection capacity:

Stripping length/sleeve length	10 mm
Mating direction	parallel to the conductor axis or circuit board
Conductor cross section rigid	0.2-1.5 mm ²
Conductor cross section flexible	0.2-1.5 mm ²
Conductor cross section, ultrasonically compacted	0.2-1.5 mm ²
Conductor cross section AWG/kcmil	24-16
Conductor cross section flexible with ferrule without plastic sleeve	0.25-1.5 mm ²
Conductor cross section flexible with ferrule with plastic sleeve	0.25-0.75 mm ² (reason for reduction d2 of the ferrule)




7.3 Label Field



Manufacturer	Weidmüller
Type	MF 10/5 CABUR MC NE WS
Article number Weidmüller	1854510000
Compatible printer	Weidmüller
Type	Printjet Advanced 230V
Article number Weidmüller	1324380000

8 Wiring

8.1 Wiring Example



8.2 Note

The signals recorded by the analog modules are very small, as compared to the digital signals. To ensure error-free operation, a careful wiring method must be followed.

The following installation guidelines should be observed:

- Avoid parallel connections between input lines and load-bearing circuits.
- Protective circuits for all relays (RC networks or free-wheeling diodes)
- The DIN rail must have an adequate mass connection.
- The lines connected to the source of the analog components must be as short as possible and parallel wiring to digital signal lines must be avoided.
- The signal lines must be shielded.
- The shielding must be connected to a shielding bus.

INFORMATION



The ground bus should be connected to the control cabinet when possible!

The S-DIAS module CANNOT be connected/disconnected while voltage is applied!

8.3 Measuring Temperature with Thermal Elements


Temperature measurement using thermocouples is based on the temperature-dependent voltage, which is generated through the combination of two conductors from different metals (alloys); this is called the Seebeck effect.

This voltage therefore exists not only at the measurement point (where it is desired), but also at the coupling between the thermal element conductors and the copper connection. The thermal voltage at this location is not desired, however, it is unavoidable. This voltage falsifies the measurement value by that of the temperature at the coupling!

An exact measurement is therefore only possible if temperature of the coupling is measured, converted to the equivalent thermal voltage of the thermal element and added to the measured thermal voltage of the servo element and the temperature calculated therefrom. The calculation is performed in the module directly.


Thermal elements can be connected directly to the connector plug of the modules (over compensating circuits when possible). For thermocouple applications where the compensating circuit is not connected to the control, the comparison measurement must be made at the junction of the thermocouple (or compensating circuit) and copper conductor.

8.4 Connecting the Thermoelement to the Control



- If the thermal element is galvanically separated, meaning not connected to earth, it is recommended that when using the thermal elements to measure the temperature in ceramic heating elements, the thermal element should be connected to the GND terminal of the control to prevent measuring signal errors caused by the voltage coupling.
- With a HW version < HW3.0 a KTY10-62 or KTY11-62 is used for thermocoupling compensation and in this case, measures the temperature directly from the S-DIAS connector X5.
- Starting with a hardware version ≥ HW3.0 the module has additional temperature sensors for thermo coupling compensation integrated. It is therefore recommended that the internal thermos coupling compensation be used when the thermal elements are connected directly to the control, so that the error can be reduced to $\leq \pm 2$ °C via the compensation.

8.5 Connecting the Thermo Element over an Intermediate Coupling without Equalization Cable



- If the thermal element is galvanically separated, meaning not connected to earth, it is recommended that when using the thermal elements to measure the temperature in ceramic heating elements, the thermal element should be connected to the GND terminal of the control to prevent measuring signal errors caused by the voltage coupling.
- The KTY10-62/KTY11-62 or KTY11-62 replacement sensor is used for thermo couple compensation and in this case, measures the temperature directly on the intermediate coupling.

9 Assembly/Installation

9.1 Check Contents of Delivery

Ensure that the contents of the delivery are complete and intact. See chapter 1.3 Contents of Delivery.

INFORMATION




On receipt and before initial use, check the device for damage. If the device is damaged, contact our customer service and do not install the device in your system.


Damaged components can disrupt or damage the system.

9.2 Mounting

The S-DIAS modules are designed for installation into the control cabinet. To mount the modules, a DIN-rail is required. The DIN rail must establish a conductive connection with the back wall of the control cabinet. The individual S-DIAS modules are mounted on the DIN rail as a block and secured with latches. The functional ground connection from the module to the DIN rail is made via the grounding lug on the back of the S-DIAS modules. The modules must be mounted horizontally (module label up) with sufficient clearance between the ventilation slots of the S-DIAS module blocks and nearby components and/or the control cabinet wall. This is necessary for optimal cooling and air circulation to ensure proper function up to the maximum operating temperature.



Recommended minimum distances between the S-DIAS modules and the surrounding components or control cabinet wall:



a, b, c ... distances in mm (inches)

10 Transport/Storage

This device contains sensitive electronics. During transport and storage, high mechanical stress must therefore be avoided.

For storage and transport, the same values for humidity and vibration as for operation must be maintained!

Temperature and humidity fluctuations may occur during transport. Ensure that no moisture condenses in or on the device, by allowing the device to acclimate to the room temperature while turned off.

When sent, the device should be transported in the original packaging if possible. Otherwise, packaging should be selected that sufficiently protects the product from external mechanical influences. Such as cardboard filled with air cushioning.

11 Storage

When not in use, store the device according to the storage conditions. See chapter 10 Transport/Storage.

INFORMATION



During storage, ensure that all protective covers (if available) are placed correctly, so that no contamination, foreign bodies or fluids enter the device.

12 Maintenance

During maintenance as well as servicing, observe the safety instructions from chapter 2 Basic Safety Directives.

12.1 Service

This product was constructed for low-maintenance operation.

12.2 Repair

In the event of a defect/repair, send the device with a detailed error description to the address listed at the beginning of this document.

For transport conditions, see chapter 10 Transport/Storage.

13 Disposal



INFORMATION

Should you need to dispose of the device, the national regulations for disposal must be followed.

The device appliance must not be disposed of as household waste.



14 Addressing

14.1 Address Mapping Overview

Address (hex)	Size (bytes)	Access type	Description	
0000	128	w	Cyclical data to the firmware	
0000	0	w	No data available	
0080	128	r	Cyclical data to the HW class	
0080	2	r	Status	
			Bit 0	24 V DC not OK
			Bit 1	not synchronized
			Bit 2	FLASH calibration data checksum error
			Bit 3	RAM calibration data checksum error
			Bit 4	invalid calibration data
			Bit 5	S-DIAS cyclic time not supported
			Bit 6-11	reserved
			Error information	
			Bit 12-15	error codes
			00	no errors occurred
			01	periphery could not be initialized
			02	system clock could not be initialized
			03-14	reserved
			15	undefined error occurred
0082	2	r	Temperature input 1	
0084	2	r	Temperature input 2	
0086	2	r	Temperature input 3	
0088	2	r	Temperature input 4	
008A	2	r	Temperature input 5	
008C	2	r	Temperature input 6	
008E	2	r	Temperature input 7	
0090	2	r	Temperature input 8	
0092	2	r	KTY temperature input 1	
0094	2	r	KTY temperature input 2	

Address (hex)	Size (bytes)	Access type	Description	
0096	2	r	Bit 0	cable break TMP_1
			Bit 1	cable break TMP_2
				
			Bit 7	cable break TMP_8
			Bit 8	cable break KTY_1 (external)
			Bit 9	cable break KTY_2 (external)
			Cross-circuit detection	
			Bit 10	cable break KTY_1 (external)
			Bit 11	cable break KTY_2 (external)
			Bit 12-14	reserved
			Error information	
			Bit 15	overvoltage at one of the thermal inputs (TMP_1 to TMP_8)
0098	2	r	Internal KTY temperature input 1 (KTY_INT_1) (remains at "invalid-temperature" (= -30000) if the hardware does not support this feature)	
009A	2	r	Internal KTY temperature input 2 (KTY_INT_2) (remains at "invalid-temperature" (= -30000) if the hardware does not support this feature)	
0100	128	w	Configuration data to the firmware	
0100	2	w	Checksum over the entire configuration data	
0102	2	w	Length of the configuration data	
0104	1	w	Info (special purpose or status bits)	
			Bit 0	raw value mode 0 ... normal mode (in and output values compared) 1 ... raw values are used and provided
0104	1	w	Bit 1	reserved
			Bit 2	extended functionality 0 ... additional features are deactivated (compatibility) 1 ... additional features are activated. Contained therein, is the message counter function as well as testing the measurement range (if voltage mode is active in the thermal inputs). Additionally, the internal KTY sensors can thereby be used as a reference for the thermal inputs (address 0x010B).
			Bit 3-7	reserved
0105	1	w	Message counter (only used when bit 2 in the Info-Byte is set to address 0x0104)	
0106	1	w	Thermal element selection	
			Bit 3 ... 0	TMP_1
			Bit 7 ... 4	TMP_2

Address (hex)	Size (bytes)	Access type	Description	
0107	1	w	Thermal element selection	
			Bit 3 0	TMP_3
			Bit 7 4	TMP_4
0108	1	w	Thermal element selection	
			Bit 3 0	TMP_5
			Bit 7 4	TMP_6
0109	1	w	Thermal element selection	
			Bit 3 ... 0	TMP_7
			Bit 7 . 4	TMP_8
010A	1	w	Thermal element reference selection	
			Bit 0 ... TMP_1:	0 ... KTY_1, 1 ... KTY_2
			Bit 1 ... TMP_2:	0 ... KTY_1, 1 ... KTY_2
				
			Bit 7 ... TMP_8:	0 ... KTY_1, 1 ... KTY_2
010B	1	w	Thermal element reference selection – internal/external (only when the new features (Bit 2 in the info-byte at address 0x0104) are activated)	
			Bit 0 ... TMP_1:	0 ... KTY external, 1 ... KTY internal
			Bit 1 ... TMP_2:	0 ... KTY external, 1 ... KTY internal
				
			Bit 7 ... TMP_8:	0 ... KTY external, 1 ... KTY internal
			Note: If “KTY external” is selected, the KTY input configured at address 0x010A is used. If “KTY internal” is selected, KTY_INT_1 is used for TMP_1 to TMP_4 and for TMP_5 to TMP_8, KTY_INT_2 is used.	
0180	128	r	Configuration data to the HW class	
0180	2	r	Checksum over the entire configuration data	
0182	2	r	Length of the configuration data	
0184	2	r	Firmware version	
0186	1	r	Message counter (only used when bit 2 in the Info-Byte is set to address 0x0104)	
0187	1	r	reserved	

15 Supported Cycle Times

15.1 Cycle Times below 1 ms (in μs)

FW	50	100	125	200	250	500
$\geq V1.00$				x	x	x

x = supported

15.2 Cycle Times equal to or higher than 1 ms (in ms)

FW	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
$\geq V1.00$	x	x		x				x								x

x = supported

FW	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32
$\geq V1.00$																x

x = supported

Changes Chart

Change date	Affected page(s)	Chapter	Note
18.10.2017	17	7.3 Label Field	Chapter added
	22	9 Assembly/Installation	Graphic replaced
09.11.2017	1		Text
	13	5.4 Miscellaneous	HW version
	20	8.4 Connecting the Thermoelement to the Control	Graphics and text changed
	28	14.1 Address Mapping Overview	changed
15.07.2019	1		Temperature sensor KTY11-62 added
14.11.2019	31	15 Supported Cycle Times	Chapter added
03.04.2020	11	5.2.2 Measuring Ranges Thermocouples	Thermocouple values adjusted
13.08.2020	31	15 Supported Cycle Times	FW version V1.00 adapted to FW version $\geq$ V1.00 + x=supported inserted
08.09.2020		9 Hardware class AI 088-1	Chapter added
04.11.2020	22	9.2 Mounting	Expansion functional ground connection
26.07.2023		Document	General chapters added, design
14.01.2026		Einleitung	KTY11-62 Replacement sensor added
	10	5.2 Temperature Inputs for Thermocoupling Compensation Specifications	
	19	8.3 Measuring Temperature with Thermal Elements	

16 Hardware Class

The HW classes are used to configure the module under LASAL CLASS and this document is available in the LASAL CLASS help.

AI088_1

Hardware class AI088_1 for the S-DIAS input module AI 088-1

```

SDIAS:13, AI088_1 (AI088_11)
S Class State (ClassState) <-[]->
S Device ID (DeviceID) <-[]->
S FPGA Version (FPGAVersion) <-[]->
S Hardware Version (HwVersion) <-[]->
S Serial Number (SerialNo) <-[]->
S Retry Counter (RetryCounter) <-[]->
O LED Control (LEDControl) <-[]->
S Firmware Version (FirmwareVersion) <-[]->
+ S Firmware Status (FWErrorBits) <-[]->
    ----- Temperature Inputs -----
I Temperature Input 1 (TMP_1) <-[]->
I Temperature Input 2 (TMP_2) <-[]->
I Temperature Input 3 (TMP_3) <-[]->
I Temperature Input 4 (TMP_4) <-[]->
I Temperature Input 5 (TMP_5) <-[]->
I Temperature Input 6 (TMP_6) <-[]->
I Temperature Input 7 (TMP_7) <-[]->
I Temperature Input 8 (TMP_8) <-[]->
I KTY Input 1 (KTY_1) <-[]->
I KTY Input 2 (KTY_2) <-[]->
I Internal KTY 1 (KTY_Int_1) <-[]->
I Internal KTY 2 (KTY_Int_2) <-[]->
S Cable Break (CableBreak) <-[]->
S Short circuit (ShortCircuit) <-[]->
ALARM:00, Empty

```

This hardware class is used to control the AI 088-1 hardware module. The thermal element input card has 8 thermal element inputs for all conventional thermal element types. Two inputs for KTY temperature sensors for coupling compensation are provided. More information on the hardware can be found in the module documentation.

General

ClassState	State	This server shows the actual status of the hardware class.										
DeviceID	State	The device ID of the hardware module is shown in this server.										
FPGAVersion	State	FPGA version of the module in 16#XY (e.g. 16#10 = version 1.0).										
Hardware Version	State	Hardware version of the module in format 16#XXYY (e.g. 16#0120 = Version 1.20)										
Serial Number	State	The serial number of the hardware module is shown in this server.										
Retry Counter	State	This server increments when a transfer fails.										
LED control	Output	With this server, the application LED of the S-DIAS module can be activated to find the module in the network more quickly. The following status are possible: <table><tr><td>0</td><td>LED off</td></tr><tr><td>1</td><td>LED on</td></tr><tr><td>2</td><td>blinks slowly</td></tr><tr><td>3</td><td>blinks rapidly</td></tr></table>	0	LED off	1	LED on	2	blinks slowly	3	blinks rapidly		
0	LED off											
1	LED on											
2	blinks slowly											
3	blinks rapidly											
Required	Property	This client is active by default, which means that the S-DIAS hardware module at this position is mandatory for the system and can under no circumstances be disconnected or return an error. Otherwise, the entire hardware deactivated. If the hardware module is missing or removed, an S-DIAS error is triggered. If his client is initialized with 0, the hardware module located in this position is not mandatory. This means that it can be inserted or removed at any time. However, which components identified as "not required" should be selected with regard to the safety of the system.										
Firmware Version	State	The firmware version of the hardware module is shown in this server.										
Firmware Status	State	In this server, the status bits of the FW are shown. The respective bits mean the following: <table><tr><td>Bit 0</td><td>DC not OK</td></tr><tr><td>Bit 1</td><td>no Sync available</td></tr><tr><td>Bit 2</td><td>Flash Data CRC Error</td></tr><tr><td>Bit 3</td><td>Ram Data CRC Error</td></tr><tr><td>Bit 4</td><td>invalid EEPROM version</td></tr></table>	Bit 0	DC not OK	Bit 1	no Sync available	Bit 2	Flash Data CRC Error	Bit 3	Ram Data CRC Error	Bit 4	invalid EEPROM version
Bit 0	DC not OK											
Bit 1	no Sync available											
Bit 2	Flash Data CRC Error											
Bit 3	Ram Data CRC Error											
Bit 4	invalid EEPROM version											

Analog Inputs 1-8

Temperature Input [1-8]	Input	Temperature input 1-8, status query over read() Temperature values in 1/10 °C. With open input the hardware class returns -2147483632.
Cable Break	State	Cable break detection
		Bit 0 cable break at temperature input TMP_1
		Bit 1 cable break at temperature input TMP_2
		Bit 2 cable break at temperature input TMP_3
		Bit 3 cable break at temperature input TMP_4
		Bit 4 cable break at temperature input TMP_5
		Bit 5 cable break at temperature input TMP_6
		Bit 6 cable break at temperature input TMP_7
		Bit 7 cable break at temperature input TMP_8
		Bit 8 cable break at temperature input KTY_1
Bit 9 cable break at temperature input KTY_2		
Short Circuit	State	Short circuit detection
		Bit 0 short circuit at temperature input KTY_1
		Bit 1 short circuit at temperature input KTY_2
Thermocouple element select [1-8]	Property	Thermocouple selection for the temperature inputs
		0 Type J (Fe-CuNi -10... +850 °C)
		1 Type K (NiCr-Ni -40... +1200 °C)
		2 Type T (Cu-CuNi -40... +400 °C)
		3 Type E (NiCr-CuNi 0... +640 °C)
		4 Type N (NiCrSi-NiSi -80...+1300 °C)
		5 Type S (Pt10Rh-Pt -50...+1768 °C)
		6 Type R (Pt13Rh-Pt -50...+1768 °C)
		7 Type B (Pt30Rh-Pt6Rh 0...+1820 °C)
		8 Type L (Fe-CuNi 0... +840 °C)
		9 Type U (Cu-CuNi 0... +600 °C)
		10 AnalogIn (0 ... 50mV) [µV]

Reference temperature sensor select [1-8]	Property	Selecting the reference temperature sensor.
		0 KTY1
		1 KTY2
		2 Internal KTY
KTY Input [1-2]	Input	KTY temperature inputs, status query over read()With open input the hardware class returns -2147483632.
Internal KTY [1-2]	Input	Temperature value internal KTY Internal KTY 1: for the inputs TMP_1 to TMP_4. Internal KTY 2: for the inputs TMP_5 to TMP_8. The temperature values are shown in 1/10 °C. If no internal KTY sensors are selected, -2147483632 is shown.

Communication Interfaces

ALARM	Downlink	With this downlink the corresponding alarm class can be placed via the hardware editor.
-------	----------	---