

AccessControl



The AccessControl Add-On provides extensive user management, which enables the creation, editing or deletion of multiple users. Users can also be assigned different rights via levels. In addition, all user data can be exported to a USB stick or a USB stick can be imported to, for example, load into a different CPU.

Users can either log in to the terminal directly using a password or with a USB stick. This Add-On contains the program elements for the LASAL CLASS project, as well as the LASAL SCREEN projects for multiple resolutions.

FEATURES

- User login, change and logout
- Level-based access rights
- Creating, editing and deleting users
- Login with USB Stick
- Functions for export & import

SOFTWARE VERSIONS

Design environment	LASAL CLASS 2, LASAL SCREEN, LASAL Machine Manager
Operating system	RTOS, Salamander

SYSTEM REQUIREMENTS

Performance Index	A > B > C > D > E				
Visualization Memory Requirements					
Code Size [KB]	75				
User Heap [KB]	19				
LSE Project Size [KB]	18				
SRAM [bytes]	0				

AVAILABLE RESOLUTIONS [px]

800x480, 800x600, 800x1280, 1024x768, 1280x800, 1366x768

