

Tableau

Mounting Components

Mounting Instructions

The following instructions must be followed when installing the terminal:

- The screw-in brackets can be tightened with a torque of **0.15-0.2 Nm**. For this purpose, a 3 x 0.5 flat-tip screw driver is required.
- To avoid damage to the frame, it is important to ensure that during installation, the contact surface is clean (free of debris, uneven areas). Unevenness can lead to stress on the frame or contamination from dust and water.

