




LSE SafetyDownload



The SafetyDownload Add-On is used to load a Safety application into a Safety CPU without using the LASAL SAFETYDesigner. This allows updating the Safety software without a programming device.

Included in delivery, are the most essential functions for the display and adapting the Safety CPU software.

This Add-On contains the program elements for the LASAL CLASS project, as well as the LASAL SCREEN projects for multiple resolutions.

FEATURES

- Download and verify the Safety software
- Set CPU to Service Mode and Run Mode
- Changing the Safety CPU password
- Display of the Safety CPU status

FACTS

Development environment	LASAL CLASS 2, LASAL SCREEN, LASAL Machine Manager
Operating system	RTOS, Salamander
Performance index	A > B > C > D > E